TouchKit Touch Driver Installation Guide

Version: 1.22.3025
Operation System: Mac OSX 10.6
Release Date: 07-25-2012

Contents

1. Installation Procedure 2
2. TouchKIt Utility Setting 4
3. Uninstall Driver 6

EETI Confidential


1. Installation Procedure

Please unzip the driver package and launch TouchKit Installation procedure.

1.1 Please unzip the driver package and launch TouchKit Installation procedure.



1.2 Select Install button to continue.




ETI Confidential

1.3 Select destination to install, than select Continue Installation.



1.4 When installation success, press Restart to restart your computer.




1.5 Restart Computer.

ETI Confidential

2. TouchKit Utility Setting


2.1 Launch TouchKit utility

You can launch TouchKIt Utility via \Appliation\ TouchKit.app




2.2 Calibration

To launch 4 point calibration, press 4 pts Cal to execute the procedure.




ETI Confidential

To launch 25 points calibration, press Advance->25 pts Cal



2.3 We suggest that users enable TPMon Open at Login in TouchKit utility. TPMon will monitor display setting changes and notify touch driver. Users use dual monitor display must enable TPMon.




ETI Confidential

3. Uninstall Driver


3.1 Delete kernel extension file

Delete /System/Library/Extensions/CUSBInterfce.kext



3.2 Delete TouchKit Utility


Delete /Applications/ TouchKit.app



ET Confidential

3.3 Delete TPMon Utility

Delete /Applications/TPMon.app



EETI Confidential